


Data reduction of the Echelle spectra using IRAF

Mauricio Cabezas
23.08.2023

Workshop on observational techniques
21 August – 1 September 2023 at Ondřejov observatory



IRAF - first steps

<https://iraf.net>

help task

Plot spectrum

splot spec.fit

Plot set of spectra

specplot @spec.list

specplot e*.fit,01.fit,02.fit...

Check header

imhead spec.fit/@spec.list l+ | page

Select some field from header

hselect spec.fit/@spec.list \$l,obj-name,exptime yes

Check stats of spectrum

imstat spec.fit/@spec.list

See image with ds9

!ds9 &

display spec.fit Nframe (nframe=1,...,12)

EDIT:

1) login.cl line ~34

set stdimage = **imt4096**

set imextn = "oif:imh fxf:**fit,fits** ..."

2) include data of Ondrejov observatory in the database, edit file **obsdb.dat** (path:

~miniconda3/envs/iraf38/iraf/noao/lib/obsdb.dat)

```
fix32 (on merak)

This is the EXPORT version of IRAF V2.16 supporting PC systems.

Welcome to IRAF.  To list the available commands, type ? or ??.  To get
detailed information about a command, type `help <command>'.  To run a
command or load a package, type its name.  Type `bye' to exit a
package, or `logout' to get out of the CL.  Type `news' to find out
what is new in the version of the system you are using.

Visit http://iraf.net if you have questions or to report problems.

The following commands or packages are currently defined:

(Updated on 2013-12-13)

adccdrom.  deitab.  images.  mtools.  softtools.  upsquid.
cfh12k.    esowfi.  kepler.  nfextern.  sqiid.    utilities.
cirred.    finder.  language.  noao.    stecf.    vo.
ctio.      fitsutil.  lists.    obsolete.  stdas.    xdimsum.
cutoutpkg. gemini.  mem0.     plot.     system.   xray.
dataio.    gmisc.    mscdb.    proto.    tables.
dbms.      guiapps.  mscred.   rvsao.    ucsclris.

ec1>
```

observatory = "ondrejov"

name = "Ondrejov observatory"

longitude = 345:12:59

latitude = 49:54:38

altitude = 528

timezone = -1

OESRED.CL


- SEMI automatic
- always check your data!

imstat
ds9
splot

- Divided in two parts: Calibration and Science.
Useful for many exposures same night
- Parameters were tested and works exclusively for OES.
- for now, recommend stepbystep

- WORKSHOP/

- oesred.cl
- 20230629
 - e2023*.fit
- 20232308
 - e2023*.fit



*Imhead *.fit* (quick inspection)

epar oesred (or any task- **edit parameter**)

Quit :q
Go! :g

Image Reduction and Analysis Facility

PACKAGE = clpackage
TASK = oesred

input = e202306290034.fit Spectrum target to reduce(.fit)
(output = alplyr) Output filename
(idtarget= alp Lyr) Target name on header
(napertu= 49) Number of apertures to be found
(id = 0022) Observation id number

CALIBRATION PARAMETERS

(orgfile= yes) do you want organize files?
(zerocom= no) Combine zero level images?
(trimcal= no) Trim flat and comp?
(iftrimc= no) Use trim flat & comp?
(zerocor= no) Apply zero level correction to flat & comp?
(compcom= no) Combine comparison lamp images?
(flatcom= no) Combine flat field images?
(flatapa= no) Extract flat apertures?
(compapa= no) Extract comparison apertures?
(iddatab= no) Use database folder for identification?
(idfolde= idcomp_2307) folder name with identification database
(idencom= no) Identify features in spectrum for dispersion solution?

OBJECT PARAMETERS

(trimob = no) Trim object?
(iftrimo= no) Use trim object?
(zerocor= no) Apply zero level correction to object?
(crays = no) Remove cosmic rays?
(ifcrays= no) Use object with cosmic rays extraction?
(objecta= no) Extract object apertures?
(flatcor= no) Apply flat correction to object?
(helioco= no) calculate JD + heliocentric correction?
(idref = no) refer database identification to images?
(norm = no) normalize spectra?
(ncombin= no) combine normalized spectra?

TASK PARAMETERS

(nfuncti= legendre) Continuum fitting function
(norder = 5) Order of continuum fitting function
(t_funct= spline3) Trace apertures fitting function
(t_order= 5) Order of apertures fitting function
(edit_o = no) Edit object apertures?
(review_ = no) Review object apertures?
(mode = ql)

1) Initial parameters!

Check type of "image":

flat: flat fields

zero: bias

comp: ThAr comparison spectra

Object: science

imhead e*.fit(short way)

- print list filename and object type

hselect e*.fit \$!,object yes

- check header!

imhead e202109060001.fit l+ | page

- for example, alp Lyr spectrum.

- take note about the filename and the target name in the header!

```
DISPAXIS= 1 / Dispersion axis along lines
GRATNAME= '3' / Grating name - ID
SLITTYPE= 'BLADE' / Type of slit - blade or image slicers
AUTOGUID= 'NO' / Status of autoguider system
SLITWID = 0.6 / Slit width in mm
COLIMAT = 'open' / Collimator mask status
TLE-TRCS= '0' / Correction Set
TLE-TRGV= '-22.3 -15.3' / Guiding Value
TLE-TRHD= '-46.9083 38.8601' / Hour and Declination Axis
TLE-TRRD= '183656.340 +38470' / Right ascension and Declination
TLE-TRUS= '0.0000 0.0000' / User Speed
SGH-MCO = 'coude' / Mirror Coude Oes
SGH-MSC = 'star' / Mirror Star Calibration
SGH-OIC = 2 / OES Iodine cell
TM-DIFF = -2 / T1688068811 - P1688068813
OBJECT = 'alp Lyr' / Title of observation
IMAGETYP= 'object' / Type of observation, eg. FLAT
OBSERVER= 'Kubatova, Novotny' / Observers
SYSVER = 'PESO exported.exp'
READSPD = '100kHz'
FILENAME= 'e202306290034.fit'
CAMFOCUS= 3080. / Camera focus position
SPECTEMP= 22.9 / 18288
SPECFILT= 0 / Spectral filter
SLITHEIG= 1.07 / Slit height in mm
```

ALWAYS keep raw data as backup!!

```
64 ##### define variables
65 name="Mauricio Cabezas "
66 email='mauricio.cabezas@asu.cas.cz '
```

Good to know and have contact who performed the reduction

```
cl
e202306290029.fit[2048,2048][ushort]: comp
e202306290030.fit[2048,2048][ushort]: comp
e202306290031.fit[2048,2048][ushort]: zero
e202306290032.fit[2048,2048][ushort]: zero
e202306290033.fit[2048,2048][ushort]: zero
e202306290034.fit[2048,2048][ushort]: alp Lyr
e202306290035.fit[2048,2048][ushort]: Cyg X-1
e202306290036.fit[2048,2048][ushort]: HD 340883
e202306290037.fit[2048,2048][ushort]: HD 339368
e202306290038.fit[2048,2048][ushort]: comp
e202306290039.fit[2048,2048][ushort]: comp
e202306290040.fit[2048,2048][ushort]: comp
e202306290041.fit[2048,2048][ushort]: comp
```

```
cl
I R A F
Image Reduction and Analysis Facility
PACKAGE = clpackage
TASK = oesred

input = e202306290034.fit Spectrum target to reduce(.fit)
(output = alplyr) Output filename
(idtarget= alp Lyr) Target name on header
(napertu= 49) Number of apertures to be found
(id = 0022) Observation id number
```

input:The complete fit file name of our target, science

output:Filename of the final reduced spectrum > “output-id.fit”, why ‘id’?
→ same target, same night

Idtarget: EXACT name of the target which is in the header!!

naperture:Number of apertures, important if we wanna use the wavelenght calibration database. Keep in 49.

id:recommended the last four numbers of the fit file

2) sort files!

- complete first set of parameters, in the part of calibration set:

orgfile = yes

:go

After this step files are organized, you can check each folder and files.

Example:


imstat @flat.dat

#	IMAGE	NPIX	MEAN	STDDEV	MIN	MAX
	e202109060006.fit	4194304	931.1	2621.	0.	25203.
	e202109060007.fit	4194304	949.1	2679.	0.	25797.
	e202109060008.fit	4194304	944.7	2664.	0.	25560.
	e202109060009.fit	4194304	941.4	2654.	0.	25521.
	e202109060010.fit	4194304	940.2	2649.	0.	25405.

- visual inspection:

!ds9 &

display e202306290011.fit 1




```
input = e202306290034.fit Spectrum target to reduce(.fit)
(output = alplyr) Output filename
(idtarge= alp Lyr) Target name on header
(napertu= 49) Number of apertures to be found
(id = 0022) Observation id number

# CALIBRATION PARAMETERS

(orgfile= yes) do you want organize files?
(zero com= no) Combine zero level images?
(trim cal= no) Trim flat and comp?
(if trim= no) Use trim flat & comp?
```

**Before each run be
sure we are in the
MAIN folder (20230629/)!
pwd**



3) Combine zeros!


- before, is possible edit the list **zero.dat**
- change the previous task to "no"

```
orgfile = no
zerocom = yes
:go
```

- new file: **Zero.fit**

```
# CALIBRATION PARAMETERS

(orgfile=          no) do you want organize files?
(zerocom=          yes) Combine zero level images?
(trimcal=          no) Trim flat and comp?
(iftrimc=          no) Use trim flat & comp?
(zerocor=          no) Apply zero level correction to flat & c
(compcom=          no) Combine comparison lamp images?
```



```
111
112 ##### ZEROCOMBINE
113 if (access("zero/Zero.fit")){
114     zerocomb=no
115 }
116 if (zerocomb==yes){
117     cd "zero/"
118     unlearn zerocombine
119     zerocombine.reject="minmax"
120     zerocombine.rdnoise= "READNOIS"
121     zerocombine.gain   = "GAIN"
122     zerocombine (input="@zero.dat",output="Zero.fit")
123     cd "../"
124 }
```


4) trim flat and comp (recommended)

- completely optional, but usually the first and last pixel of each aperture is saturated and can be annoying during normalization.
- related with lines database 'idcomp'

zerocom = no


trimcal = yes

iftrimc = yes

:go

- new files, prefix **T**

Te*.fit



4) trim flat and comp (recommended)


If we apply trim and you want to use the trimmed images, you need to set iftrimc=yes during the whole reduction!

```
133  if (trimcal==yes){
134      unlearn ccdproc
135      ccdproc.trimsec = "[2:2035,*]"
136  #   ccdproc.trimsec = "[5:2025,800:1500]"
137      ccdproc.trim = yes
138      ccdproc.fixpix = no
139      ccdproc.overscan = no
140      ccdproc.darkcor=no
141      ccdproc.zerocor=no
142      ccdproc.flatcor=no
143      #
144      cd "flat/"
145      ccdproc.ccdtype = "flat"
146      ccdproc (images="@flat.dat",output="T@flat.dat")
147      cd "../"
148      #
149      cd "comp/"
150      ccdproc.ccdtype = "comp"
151      ccdproc (images="@comp.dat",output="T@comp.dat")
152      cd "../"
```

5) Bias correction → flat and comp

trimcal = no
iftrimc = yes
zerocor = yes
:go

- new files, prefix **Z**
ZTe*.fit



5) Bias correction flat and comp

```
156 ##### SUBTRACT zero
157 if (zerocorcal==yes){
158   # imarith (operand1="flat/flat.fits", op="/", operand2="zero/Zero.fits", result="Zflat.fits")
159   # imarith (operand1="comp/comp.fits", op="/", operand2="zero/Zero.fits", result="Zcomp.fits")
160   unlearn ccdproc
161   ccdproc.ccdtype="zero"
162   # ccdproc.trimsec = "[5:2025,800:1500]"
163   ccdproc.fixpix = no
164   ccdproc.overscan = no
165   ccdproc.darkcor= no
166   ccdproc.zerocor=no
167   ccdproc.flatcor=no
168   #
169   cd "flat/"
170   ccdproc.ccdtype="flat"
171   ccdproc.zerocor=yes
172   ccdproc.zero="../zero/Zero.fit"
173   if (iftrimc==yes){
174     ccdproc (images="T@flat.dat",output="ZT@flat.dat")
175   } else {
176     ccdproc (images="@flat.dat",output="Z@flat.dat")
177   }
178   cd "../"
179   #
180   cd "comp/"
181   ccdproc.ccdtype="comp"
182   ccdproc.zerocor=yes
183   ccdproc.zero="../zero/Zero.fit"
184   if (iftrimc==yes){
185     ccdproc (images="T@comp.dat",output="ZT@comp.dat")
186   } else {
187     ccdproc (images="@comp.dat",output="Z@comp.dat")
188   }
189   cd "../"
190 }
```

6) Combine comp (ThAr)

iftrimc = yes (keep "yes")


zerocor = no

compcom = yes

:go

- new file

ZTcomp.fit




7) Combine flat field

iftrimc = yes
compcom = no
flatcom = yes
:go

- new file

ZTflat.fit



6) and 7) Combine comp/flat field

```
193 ##### COMBINE - comp/lamp
194 if (compcomb==yes){
195     cd "comp/"
196     unlearn imcombine
197     # imcombine.reject = "none"
198     imcombine.reject = "none"
199     imcombine.lsigma = 3
200     imcombine.hsigma = 3
201     imcombine.rdnoise= "READNOIS"
202     imcombine.gain    = "GAIN"
203     imcombine.scale   = "exposure"
204     imcombine.expname="EXPTIME"
205     # imcombine (input="@comp.dat",output = "comp.fits")
206     if (iftrimc==yes){
207         imcombine (input="ZT@comp.dat",output = "../ZTcomp.fit")
208     } else {
209         imcombine (input="Z@comp.dat",output = "../Zcomp.fit")
210     }
211     cd "../"
212 }
213
214 ##### COMBINE flat
215 if (flatcomb==yes){
216     cd "flat/"
217     if (iftrimc==yes){
218         imcombine (input="ZT@flat.dat",output = "../ZTflat.fit")
219     } else {
220         imcombine (input="Z@flat.dat",output = "../Zflat.fit")
221     }
222     cd "../"
223 }
```

8) Model apertures - Flat

iftrimc = yes

flatcom = no

flatapa = yes

:go

Find apertures for Ztflat? (yes):

Number of apertures to be found automatically (49):

Resize apertures for ZTflat? (yes):

Edit apertures for Ztflat? (yes):

- accept everything with “enter” or typing “yes”. Default answer in parenthesis.

- value in parenthesis (yes/no) is Predefined. press ENTER

- in order to do everything a bit easy/fast. We will use a database for wavelength calibration, for that we need to choose 49 apertures.

Background fitting is not necessarily because overlapping.

```
# CALIBRATION PARAMETERS

(orgfile=          no) do you want organize files?
(zero com=         no) Combine zero level images?
(trim cal=         no) Trim flat and comp?
(iftrimc=         yes) Use trim flat & comp?
(zero cor=         no) Apply zero level correction to flat & comp?
(comp com=         no) Combine comparison lamp images?
(flat com=         no) Combine flat field images?
(flat apa=         yes) Extract flat apertures?
(comp apa=         no) Extract comparison apertures?

More
Find apertures for ZTflat? (yes):
Number of apertures to be found automatically (49):
Resize apertures for ZTflat? (yes):
Edit apertures for ZTflat? (yes):
```


CURSOR KEY - interactive

Good practice:

- **NEVER** resize the window directly when interactive is activated!
if yes → ':' resize → enter
- **NEVER** do click on the interactive window!
if yes → click on green square → Delete

Help window: '?'

q+q → exit help

Window: w+e+e → Zoom bottom left/top right corner

w+a → redraw/ show all

w+u/d/l/r → move up/down/left/right

```
APEXTRACT CURSOR KEY SUMMARY

? Print help          j Set beam number      u Set upper limit(s)
a Toggle all flag     l Set lower limit(s)   w Window graph
b Set background(s)   m Mark aperture        y Y level limit(s)
c Center aperture(s)  n New uncentered ap.   z Resize aperture(s)
d Delete aperture(s)  o Order ap. numbers    I Interrupt
e Extract spectra     q Quit                  + Next aperture
f Find apertures      r Redraw graph          - Previous aperture
g Recenter aperture(s) s Shift aperture(s)    . Nearest aperture
i Set aperture ID     t Trace aperture(s)

APEXTRACT COLON COMMAND SUMMARY


:apertures      :center      :npeaks      :show      :t_width
:apidtable      :clean       :nsubaps     :skybox     :threshold
:avglimits      :database    :nsum        :t_function :title
:b_function     :extras     :order       :t_grow     :ulimit
:b_grow         :gain       :parameters  :t_high_reject :upper
:b_high_reject  :image      :peak        :t_low_reject :usigma
:b_low_reject   :line       :plotfile    :t_naverage  :weights
:b_naverage     :llimit     :r_grow      :t_niterate  :width
:b_niterate     :logfile    :radius      :t_nlost     :write
:b_order        :lower      :read        :t_nsum      :ylevel
:b_sample       :lsigma     :readnoise   :t_order     :
:background     :maxsep     :saturation  :t_sample    :
:bkg            :minsep     :shift       :t_step

APEXTRACT CURSOR KEYS



? Print help
a Toggle the ALL flag
b an Set background fitting parameters
c an Center aperture(s)
abextract options-(46%)--line 34--file 1 of 1
```

8) Model apertures - Flat

- first aperture near the pixel $\sim 860-890$
mark: **m**




8) Model apertures - Flat



- delete extra apertures
We need only 49
→ over the aperture
Then : **d**


First aperture
Number 1,
no 50

Sort: **o**
'1'
enter



- check apertures,
Zoom in/out and
Aperture numbers

All right? → **'q'**
'Trace apertures for Ztflat?
(yes)



8) Model apertures - Flat



Fit curve to aperture N of Ztflat interactively (yes): YES

Write apertures for ZTflat to database (yes):

Extract aperture for ZTflat? (yes):


Review extracted spectra from ZTflat? (yes): YES

Review extracted spectrum for aperture 1 from ZTflat? (yes)
YES




Polynomial fitting of
the echelle orders

- change order :o **N**
- change function:
:f **spline3/legendre/
chebyshev**
- relative residuals **k**
- residuals (px) **j**
- aperture **h**



8) Model apertures - Flat

- new file: **AZTflat.fit**



```
241 #####APERTURES - APALL FLAT
242 if (flatapall==yes){
243     echelle
244     unlearn apall
245     apall.format = "echelle"
246
247     apall.extras=no
248     apall.extract=yes
249
250     apall.nsum=15
251
252     apall.lower=-5
253     apall.upper=5
254     apall.b_order=3
255     apall.b_sample="-10:-6,6:10"
256
257     apall.nfind=nap
258     #apall.minsep=10
259     apall.minsep=5
260     apall.maxsep=1000
261
262
263     apall.ylevel = 0.04
264     apall.bkg=yes
265     #apall.bkg=no
266
267     apall.t_nsum = 10
268     apall.t_function = tfunc
269     apall.t_niter=100
270     apall.t_order=torder
271
272     apall.clean=no
273     apall.readnoi= 0
274     apall.gain = 1
275
276
277
278     #apall.width=9
279     #apall.width=5
280     # apall.weights = "none"
281     apall (input=inflat, output = "A"//inflat)
282 }
```

9) Model apertures - Comparison lamp

- Template: AZTflat.fit

iftrimc = yes

flatapa = no

compapa = yes

:go

Edit apertures for ZTcomp? (yes):

Can be “no” but always is better to check it!

q

Write apertures for ZTcomp to database (yes):

Extract aperture spectra for ZTcomp? (yes):


Review extracted spectra from ZTcomp? (yes):

Review extracted spectrum for aperture 1 from ZTcomp? (yes) YES


- if you are using database, check if the first aperture corresponds to the first aperture in the atlas. (inside folder **idcomp_***

```
# CALIBRATION PARAMETERS


(orgfile=          no) do you want organize files?
(zero com=         no) Combine zero level images?
(trim cal=         no) Trim flat and comp?
(if trimc=         yes) Use trim flat & comp?
(zero cor=         no) Apply zero level correction to flat & comp?
(comp com=         no) Combine comparison lamp images?
(flat com=         no) Combine flat field images?
(flat apa=         no) Extract flat apertures?
(comp apa=         yes) Extract comparison apertures?
(id data=         no) Use database folder for identification?
(id folde=        idcomp_2307) folder name with identification database
(iden com=         no) Identify features in spectrum for dispersion sol
```



9) Model apertures - Comparison lamp



NDA0/IRAF V2.16 mauricio@mauricio Wed 12:32:54 30-Dec-2020
identify iazcomp.0001 - Ap 1
comp




9) Model apertures - Comparison lamp

- reference → **AZTflat**

- new file: **AZTcomp.fit**

```
283
284 #####APERTURES - COMP
285 if (compapall==yes){
286     apall.referen=inflat
287     apall.format = "echelle"
288     apall.find=no
289     apall.recente=no
290     apall.resize=no
291     apall.trace=no
292     apall.fittrace=no
293     apall.extras=no
294     apall.ylevel = 0.04
295     apall.extract=yes
296     apall (input=incomp, output="A//incomp//".fit")
297 }
298
```

kshop / 20230629



10) Wavelength calibration

- using database, folder “idcomp” must be in the main path

iftrimc = yes

compapa = no

iddatab = yes

idfolder = idcomp_2307

idencom = yes

:go

```
# CALIBRATION PARAMETERS

(orgfile=          no) do you want organize files?
(zerocom=          no) Combine zero level images?
(trimcal=          no) Trim flat and comp?
(iftrimc=          yes) Use trim flat & comp?
(zerocor=          no) Apply zero level correction to flat & comp?
(compcom=          no) Combine comparison lamp images?
(flatcom=          no) Combine flat field images?
(flatapa=          no) Extract flat apertures?
(compapa=          no) Extract comparison apertures?
(iddatab=          yes) Use database folder for identification?
(idfolde=          idcomp_2307) folder name with identification database
(idencom=          yes) Identify features in spectrum for dispersion so
```

- in database, lines can be shifted few pixels, in order to fix it we need to “shift” the lines of our database. If doesn’t work, recommend delete every line with **d**, and mark new lines (**m**) comparing with the atlas.

Shift → **s**


- always fit!

f (delete point **d**), **q**, **q**

- rms ~ 0.007 acceptable


- Write feature data to the database (yes)?

NOAO/IRAF V2.16 cabezas@merak Tue 22:21:55 07-Sep-2021
identify lazcomp.0001 - Ap 1
comp



No match!
Press "s"


NOAO/IRAF V2.16 mauricio@lenovo Tue 14:02:33 22-Aug-2023
identify lazcomp.0001 - Ap 1
comp



User coordinate (3996.2881):

: enter



NOAO/IRAF V2.16 cabezas@merak Tue 22:24:31 07-Sep-2021
identify lazcomp.0001 - Ap 1
comp



Recentered=39/39, pixel shift=3.33, user shift=-0.11, z=-2.7E-5, rms=0.057

10) Wavelength calibration - fit

- NO pattern in residuals
- no high order is recommended
- **d** to eliminate point
- **q, f** to refit and update plot






- better RMS, no significant
→ **q,q** to the next aperture

```
identify iazcomp.0001 - Ap 1  
Write feature data to the database (yes)?
```

- yes, 49 times :)



10) Wavelength calibration - but..if not match?? :(

- delete all lines
- **NO press F!**
- compare the Atlas and mark manually > 5 lines
mark: **m**, wavelength, **enter**
delete: **d**
zoom in/out (**w,e,e**)
- now **f** to fit, check residuals, **q**




10) Wavelength calibration - but..if not match?? :(

- **L**, automatic mark
- **f**, refit
- 'clean'
- happy, **q,q**



10) Wavelength calibration

- using the database
- for each aperture a file is created with the calibration information, which later will use as reference to the object's apertures.
- new files: **iazcomp.00**.fit**



```
315 ##### IDENTIFY 1D
316 if (idencomp==yes){
317     unlearn directory
318     unlearn scopy
319     directory.sort=yes
320     directory "identify/" | scan (iddir)
321     if (iddir=="no"){
322         mkdir (newdir="identify")
323     }
324     copy (input="A"//incomp,output="identify/")
325     cd "identify/"
326     lpar scopy
327     scopy.format="onedspec"
328     scopy (input="A"//incomp, output="iazcomp")
329     print "second"
330     unlearn refspectra
331     unlearn hedit
332     hedit.addonly=yes
333     hedit.verify=no
334     hedit.show=no
335     for (i=1; i <=nap; i+=1) {
336         printf ("iazcomp.00%02d.fit\n",(i)) | scan(ecname)
337         if (iddatabase==yes){
338             printf ("iazcomp.00%02d\n",(i)) | scan(refname)
339             hedit (images=ecname, fields="REFSPEC1", value=refname)
340         }
341         identify.coordli="linelists$thar.dat"
342         #lpar identify
343         identify (images=ecname)
344     }
345     cd "../"
346 }
347
```

10) Wavelength calibration - idcomp_* database

- pixel

- Last one is the valid


```
020
621 # Mon 16:09:08 14-Aug-2023
622 begin identify iazcomp.0020 - Ap 20
623   id iazcomp.0020
624   task identify
625   image iazcomp.0020 - Ap 20
626   aperture 20
627   aplow 1245.04
628   ahigh 1254.39
629   units Angstroms
630   features 39
631   44.33 5122.49923 5122.4995 4.0 1 1
632   248.49 5115.04518 5115.0448 4.0 1 1
633   349.35 5111.2775 5111.2781 4.0 1 1
634   390.23 5109.73442 5109.7331 4.0 1 1
635   613.85 5101.12945 5101.1299 4.0 1 1
636   692.37 5098.04247 5098.0432 4.0 1 1
637   731.70 5096.48345 5096.4848 4.0 1 1
638   767.33 5095.06367 5095.0639 4.0 1 1
639   891.65 5090.05504 5090.0513 4.0 1 1
640   912.21 5089.21879 5089.2192 6.0 1 1
641   986.44 5086.17967 5086.1774 6.0 1 1
642   1015.29 5084.9903 5084.9935 6.0 1 1
643   1100.62 5081.44574 5081.4462 6.0 1 1
644   1242.46 5075.46606 5075.4659 4.0 1 1
645   1261.72 5074.64575 5074.6465 6.0 1 1
646   1385.29 5069.33375 5069.3384 6.0 1 1
647   1416.62 5067.97393 5067.9737 4.0 1 1
648   1435.82 5067.13772 5067.1379 6.0 1 1
649   1444.03 5066.77966 5066.7773 4.0 1 1
650   1458.76 5066.13623 5066.1355 4.0 1 1
651   1493.74 5064.60369 5064.602 6.0 1 1
652   1518.46 5063.51693 5063.5157 4.0 1 1
653   1531.75 5062.93097 5062.9325 4.0 1 1
654   1551.96 5062.03813 5062.0371 4.0 1 1
655   1560.53 5061.65909 5061.6562 4.0 1 1
656   1601.01 5059.86252 5059.8611 6.0 1 1
```

- real/fitted
wavelength

- marked wavelength

11) Trim Object

IMPORTANT, first check
these parameters are ok!



```
IRAF
Image Reduction and Analysis Facility
PACKAGE = clpackage
TASK = oesred

input = e202306290034.fit Spectrum target to reduce(.fit)
(output = alplyr) Output filename
(idtarget= alp Lyr) Target name on header
(napertu= 49) Number of apertures to be found
(id = 0022) Observation id number
```

iftrimc = yes
iddatab = no
idfolder = idcomp
idencom = no

trimob = yes
iftrimo = yes
:go

```
# OBJECT PARAMETERS

(trimob = yes) Trim object?
(iftrimo= yes) Use trim object?
(zeroeor= no) Apply zero level correction to object?
(crays = no) Remove cosmic rays?
(ifcrays= no) Use object with cosmic rays extraction?
(objecta= no) Extract object apertures?
(flatcor= no) Apply flat correction to object?
(helioco= no) calculate JD + heliocentric correction?
(idref = no) refer database identification to images?
(norm = no) normalize spectra?


More
```

11) Trim Object

- trimsection has to be the same as calibration DON'T change!

```
368   if (trimob==yes){
369       unlearn ccdproc
370       ccdproc.trimsec = "[2:2035,*]"
371       ccdproc.trim = yes
372       ccdproc.fixpix = no
373       ccdproc.overscan = no
374       ccdproc.darkcor= no
375       ccdproc.zerocor=no
376       ccdproc.flatcor=no
377       #
378       cd (oname)
379       ccdproc.ccdtype = "object"
380       ccdproc (images=spec, output="T"//spec)
381       cd "../"
382   }
383
```

New file: **alplyr/Te2023*.fit**



12) Bias correction object

```
iftrimc = yes
trimob = no
iftrimo = yes
zerocor = yes
:go
```

New file: **alplyr/ZTe2023*.fit**

```
# OBJECT PARAMETERS

(trimob =          no) Trim object?
(iftrimo=         yes) Use trim object?
(zerocor=         yes) Apply zero level correction to object?
(crays  =          no) Remove cosmic rays?
(ifcrays=         no) Use object with cosmic rays extraction?
(objecta=         no) Extract object apertures?
(flatcor=         no) Apply flat correction to object?
(helioco=         no) calculate JD + heliocentric correction?
(idref  =          no) refer database identification to images?
(norm   =          no) normalize spectra?
```

/ workshop / 20230629 / alplyr

```
392
393 if (zerocorob==yes){
394     cd (oname)
395     #imarith (operand1=spec, op="/", operand2="../../zero/Zero.fits", result=
396
397     unlearn ccdproc
398     ccdproc.ccdtype="zero"
399     ccdproc.fixpix = no
400     ccdproc.overscan = no
401     ccdproc.darkcor= no
402     ccdproc.zerocor=no
403     ccdproc.flatcor=no
404     #
405     ccdproc.ccdtype="object"
406     ccdproc.zerocor=yes
407     ccdproc.zero="../../zero/Zero.fit"
408     ccdproc (images=inobject,output="Z"//inobject)
409     cd "../../"
410 }
411
```



logfile



Te20230629
0034.fit



ZTe2023062
90034.fit


13) Cosmic Rays - LACOS (*2001PASP...113.1420V*)

<http://www.astro.yale.edu/dokkum/lacomic/>

```
iftrimc = yes
iftrimo = yes
zerocor = no
crays = yes
ifcrays = yes
:go
```

- read GAIN and READtoNOISE from header

New files: **alplyr/CrZTe2023*.fit** ← cleaned
alplyr/MCrZTe2023*.fit ← mask



```
# OBJECT PARAMETERS


(trimob =          no) Trim object?
(iftrimo=         yes) Use trim object?
(zerocor=         no) Apply zero level correction to object?
(crays =          yes) Remove cosmic rays?
(ifcrays=         yes) Use object with cosmic rays extraction?
(objecta=         no) Extract object apertures?
(flatcor=         no) Apply flat correction to object?
(helioco=         no) calculate JD + heliocentric correction?
(idref =          no) refer database identification to images?
(norm =           no) normalize spectra?
```

```
412 #####COSMIC RAYS - COMP
413 if (crays==yes){
414     stdas
415     #####
416     #read gain
417     cd (oname)
418     hselect (images="Z"//inobject,fields="GAIN", exp=yes) | scan (gainh)
419     hselect (images="Z"//inobject,fields="READNOIS", exp=yes) | scan (readnh)
420     #print (gainh)
421     inputCR="Z"//inobject
422     outputCR="CrZ"//inobject
423     outmaskCR="MCrZ"//inobject
424     gainCR = gainh # 2 #3
425     readnCR = readnh #2
426     xorderCR = 3
427     yorderCR = 3
428     sigclipCR = 4.5
429     sigfracCR = 0.3
430     objlimCR = 0.75 #0 to 5, 5 more conservative discrimination
431     niterCR = 5
432     verboseCR = no
```

14) Extract apertures - Object

- Template: AZTflat.fit

```
iftrimc = yes
iftrimo = yes
crays = no
ifcrays = yes
objecta = yes
:go
```



14) Extract apertures - Object

Edit apertures for CrZTe2023*? (yes):

Review extracted spectrum for aperture 1 from CrZTe2023*? (yes)

Write apertures for CrZTe2023* to database? (yes):


q → if yes, with q you move to the next aperture

Extract aperture spectra for CrZTe2023*? (yes):

First view of our target!!!
BUT!! :)

Still in pixel :(


For example aperture 36 is
the spectral region of H-alpha



14) Extract apertures - Object

new file: **alplyr/ACrZTe2023*.fit**

```
732 #####APERTURES - OBJECT
733 if (objectapall==yes){
734     apall.referen=inflat
735     apall.format = "echelle"
736     apall.find=no
737     apall.recente=no
738     apall.resize=no
739     apall.trace=no
740     apall.fittrace=no
741     apall.extras=no
742     apall.extract=yes
743     apall.edit=edit_o
744     apall.review=review_o
745     ## check database
746     unlear directory
747     directory.sort=yes
748     directory oname//"/database/" | scan (iddir)
749     if (iddir=="no"){
750         mkdir (newdir=oname//"/database/")
751         copy (input="database/*",output=oname//"/database/")
752     }
753     ##
754     cd (oname)
755     apall (input=inobject, output="A"//inobject)
756     cd "../"
757 }
758 }
```



15) Flat correction

iftrimc = yes

iftrimo = yes

ifcrays = yes/no

objecta = no

flatcor = yes

:go


To see or plot use the task

plot spec.fit


To move between orders

(→ to the right/ higher aperture

) → to the left/ lower aperture



new file: **FACrZTe2023*.fit**




```
# OBJECT PARAMETERS

(trimob =          no) Trim object?
(iftrimo=         yes) Use trim object?
(zeroeor=         no) Apply zero level correction to object?
(crays  =         no) Remove cosmic rays?
(ifcrays=        yes) Use object with cosmic rays extraction?
(objecta=        no) Extract object apertures?
(flatcor=        yes) Apply flat correction to object?
(helioco=        no) calculate JD + heliocentric correction?
(idref  =        no) refer database identification to images?
(norm   =        no) normalize spectra?
```


15) Flat correction

new file: **FACrZTe2023*.fit**



In Flat correction we have to divide.
By dividing the science spectrum by
the flat-field image, we are effectively
correcting for the variations in

- sensitivity
- illumination
- detector response.

```
##### FLAT correction
#print ("FA"//inobject)
if (flatcor==yes){
    imarith (operand1=oname//"/A"//inobject, op="/", operand2="A"//inflat, result=oname//"/FA"//inobject)

    #imcopy("FA"//inobject,oldoutput,verb-)
    #move (files="FA"//inobject,newdir=oname//"/")
}
```

16) JD + heliocentric correction

```
iftrimc = yes
iftrimo = yes
ifcrays = no
flatcor = no
helioco = yes
:go
```

```
(ifcrays=          yes) Use object with cosmic rays extraction?
(objecta=          no) Extract object apertures?
(flatcor=          no) Apply flat correction to object?
(helioco=          yes) calculate JD + heliocentric correction?
(idref  =          no) refer database identification to images?
(norm   =          no) normalize spectra?

More
20:0:17CrZTe202306290034.fit
#              Image              jd              hjd              ljd
# SETJD: Observatory parameters for Ondrejov Observatory
#         timezone = -1
Warning: Image header parameter not found (UTMIDDLE)
# RVCORRECT: Observatory parameters for Ondrejov Observatory
#         latitude = 49:54:38
#         longitude = 345:12:59
#         altitude = 528
##YR MO DY  UT      RA      DEC      VOBS
##   HJD      VOBS  VHELIO  VLSR  VDIURNAL  VLUNAR  VANNUAL  VSOLAR
2023  6 29 20:00:17 18:36:56 38:47:01      0.0
2460125.33628      0.00      2.07      21.70      0.171      -0.004      1.907      19.625
FACrZTe202306290034.fit
scf>
```

Check long header:

imhead FCrAZTe2023*.fit I+

```
CD2_2 = 1.
HJD = 2460125.33628259
VHELIO = 2.07395459376786
VLSR = 21.6990646774371
VSUN = ' 20. 18. 30. 1900.'
```

16) JD + heliocentric correction

```
359 #CALC UTMIDDLE
360 hselect (images="other//spec,fields="TM_START", exp=yes) | scan (utstart)
361 hselect (images="other//spec,fields="EXPTIME", exp=yes) | scan (expt)
362 utmidhr=int((utstart + expt/2)/3600)
363 utmidmin=int((((utstart + expt/2)/3600)-utmidhr)*60)
364 utmidsec=int((((utstart + expt/2)/3600)-utmidhr)*60 - utmidmin)*60)
365 utmid = (utmidhr//":"//utmidmin//":"//utmidsec)
366 printf ("%d:%d:%d\n",utmidhr,utmidmin,utmidsec) | scan (utmid)
```

UTMIDDLE



```
769 # ##### SETJD + HELIOCOR
770 if (heliocor==yes){
771     cd (oname)
772     #
773     print (utmid,inobject)
774     unlearn hedit
775     hedit.addonly=no
776     hedit.verify=no
777     hedit.show=no
778     hedit (images="FA"//inobject, fields="UT", value=utmid)
779     ##hedit (images="N"//oname//".fit", fields="UT", value=utmid)
780     # hedit (images="N"//oname//".fits", fields="UTMIDDLE", value=utmid)
781     unlearn setjd
782     setjd.observatory="ondrejov"
783     setjd.epoch="epoch"
784     setjd.time="UTMIDDLE"
785     setjd (images="FA"//inobject)
786     rv
787     unlearn rvcorrect
788     rv.rvcorrect.input=yes
789     rv.rvcorrect.imupdate=yes
790     rv.rvcorrect.epoch=2000.
791     rv.rvcorrect.observatory="ondrejov"
792     rv.rvcorrect (images="FA"//inobject)
793     ##save header
794     print ("FA"//inobject)
795     #imheader (images="FA"//inobject)
796     imhead ("FA"//inobject, l+ ,> oname//".hd")
797     #dopcor.isvelocity=yes
798     #dopcor (input="N"//oname//id//".fit", output=oname//"-//id//".fit", re
799     #system.move (files=oname//"-//id//".fit",newdir="..")
800     cd "../"
801 }
```

17) Ref spectrum

iftrimc = yes

iftrimo = yes

ifcrays = no

helioco = no

idref = yes

:go

```
# OBJECT PARAMETERS

(trimob =          no) Trim object?
(iftrimo=         yes) Use trim object?
(zerocor=         no) Apply zero level correction to object?
(crays =          no) Remove cosmic rays?
(ifcrays=         yes) Use object with cosmic rays extraction?
(objecta=         no) Extract object apertures?
(flatcor=         no) Apply flat correction to object?
(helioco=         no) calculate JD + heliocentric correction?
(idref =          yes) refer database identification to images?
(norm  =          no) normalize spectra?

More
```

```
wap.0045.fit: ap = 45, w1 = 7839.5, w2 = 7970.266, dw = 0.064321, nw = 2034
[ap.0046] refspec1='iazcomp.0046'
ap.0046.fit: REFSPEC1 = 'iazcomp.0046 1.'
wap.0046.fit: ap = 46, w1 = 8017.647, w2 = 8151.399, dw = 0.06579, nw = 2034
[ap.0047] refspec1='iazcomp.0047'
ap.0047.fit: REFSPEC1 = 'iazcomp.0047 1.'
wap.0047.fit: ap = 47, w1 = 8204.084, w2 = 8340.946, dw = 0.06732, nw = 2034
[ap.0048] refspec1='iazcomp.0048'
ap.0048.fit: REFSPEC1 = 'iazcomp.0048 1.'
wap.0048.fit: ap = 48, w1 = 8399.397, w2 = 8539.591, dw = 0.068959, nw = 2034
[ap.0049] refspec1='iazcomp.0049'
ap.0049.fit: REFSPEC1 = 'iazcomp.0049 1.'
wap.0049.fit: ap = 49, w1 = 8605.969, w2 = 8788.151, dw = 0.089612, nw = 2034
ecl>
```

17) Ref spectrum

Read database of wavelength calibration and apply!


splot wap.0036.fit

NO more pixels!!! :)

→ aperture 36 → H-alpha

Check if ok

Good Wavelength calibration !!



17) Ref spectrum

New files:

ap.00XX.fit -
1D spectra in pixels

wap.00XX.fit -
1D spectra in Angstrom

wap_asc/wap.00XX.asc -
ascii file for each aperture
(useful)



```
806 ▼ if (idref==yes){
807     unlear directory
808     directory.sort=no
809     directory oname//"/" | scan (iddir)
810 ▼     if (iddir=="no"){
811         mkdir (newdir=oname)
812     }
813     cd oname//"/"
814     unlear onedspec
815     scopy.format="onedspec"
816     scopy (input="FA"//inobject, output="ap")
817     unlearn refspectra
818     dispcor.w1=INDEF
819     dispcor.w2=INDEF
820     dispcor.nw=INDEF
821     dispcor.flux=no
822     cd "../identify/"
823 ▼     system
824 ▼     for (i=1; i <=nap; i+=1) {
825         printf ("ap.00%02d.fit\n", (i)) | scan(oap)
826         printf ("iazcomp.00%02d.fit\n", (i)) | scan(ecname)
827         refspectra.sort="epoch"
828         refspectra.group="epoch"
829         refspectra.answer=yes
830         refspectra.confirm=no
831         system.move (files="//oname//"/"//oap, newdir="//identify/")
832         refspectra (input=oap, referen=ecname)
833         dispcor (input=oap, output="w"//oap)
834         system.move (files=oap, newdir="//oname)
835         system.move (files="w"//oap, newdir="//oname)
836     }
837     cd "../"
838     cd oname//"/"
839     wspectext.header=no
840     mkdir (newdir="wap_asc")
841 ▼     for (i=1; i <=nap; i+=1) {
842         printf ("ap.00%02d\n", (i)) | scan(oap)
843         wspectext (input="w"//oap//".fit", output="w"//oap//".asc")
844         system.move (files="w"//oap//".asc", newdir="wap_asc")
845     }
846     }
847     system.move (files=oname//"/".hd", newdir="wap_asc")
848     cd "wap_asc"
849     !ls wap*.asc > norm.list
850     ### create python script
851     cd "..."
```

18) Normalization

```
iftrimc = yes
iftrimo = yes
ifcrays = no
idref = no
norm = yes
:go
```

Fit [1,1] of wap.0001.fit w/ graph?
(yes|no|skip|YES|NO|SKIP) (yes):

```
(objecta=          no) Extract object apertures?
(flatcor=          no) Apply flat correction to object?
(helioco=          no) calculate JD + heliocentric correction?
(idref  =          no) refer database identification to images?
(norm   =          yes) normalize spectra?


More
wap.0001.fitfap.0001.fitnap.0001.fit
Fit [1,1] of wap.0001.fit w/ graph?  (yes|no|skip|YES|NO|SKIP) (yes):
```

18) Normalization

- change order :o N
- residuals j
- high rejection :hi N

- low rejection :lo N
- function :f legendre/spline3/chebyshev
- select region s..s
- delete region z
- delete all regions t

- zoom/window w, e..e
- resize w,a
- move right w,r
- move left w,l
- move up w,u
- move down w,d




18) Normalization

- change order :o N
- residuals j
- high rejection :hi N

- low rejection :lo N
- function :f legendre/spline3/chebyshev
- select region s..s
- delete region z
- delete all regions t

- zoom/window w, e..e
- resize w,a
- move right w,r
- move left w,l
- move up w,u
- move down w,d



18) Normalization

Advices / Good practices

- Start with low order
- Hot stars or wide lines →
Legendre or chebyshev
- sometimes faster just change
high/low rejection
- Dont frustrate if poor normalization
is Just experience, there is not
ABSOLUTE way

```
855 ##### normalization
856 if (norm==yes){
857     cd (oname)
858     unlearn continuum
859     unlearn scombine
860     continuum.type="fit"
861     continuum.function=cfunction
862     continuum.order=corder
863     continuum.naverage=10
864     continuum.markrej=no
865     continuum.niterat=2000
866     continuum.high_re=2
867     continuum.low_re=1.5
868     continuum.grow=0
869     for (i=1; i <=nap; i+=1) {
870         printf ("wap.00%02d.fit\n",i) | scan(wap)
871         printf ("fap.00%02d.fit\n",i) | scan(fap)
872         printf ("nap.00%02d.fit\n",i) | scan(nnap)
873         print (wap, fap, nnap)
874         continuum (input=wap, output=fap)
875     }
876     cd "../"
877 }
```

21) merging

iftrimc = yes

iftrimo = yes




ifcrays = no

norm = no

ncombine = yes

:go

new file: **alpLyr-0022.fit**



SPLIT

split alpLyr-0016.fit

Fit: gaussian: **k..k(or g)**

lorentzian: **k..l**

voigt: **k..v**


centroid **e..e**

snr: **m..m**

Change unit (angstrom to km/s)

:u km/s 6562.8 an

:u an



SPEC PLOT

specplot spec1.fit,spec2.fits

Change step: **step 1** (or any number)

See wavelength: **u**



snr: **m..m**

Change unit (angstrom to km/s)

:u km/s 6562.8 an

:u an

Replot: **r**



General Remarks

Thank
you!!

- The optimal reduction process always will be different for each instrument.
- IRAF “sometimes” is a bit tricky, but really useful.
- Quick check/inspection of spectra!!
- Versatil program because many parameters (sometimes too many).
- Pre-defined task.
- “opensource” you can write your own task/package.
- Xgterm – nice interactive tool.
- Slow with computation, python/idl/fortran would be good option.